



Main riser inspection and maintenance schedule

Before every jump

- The 3-ring system should be inspected before every jump.

While the system is in service , the following maintenance is recommended to be done every month.

- The main risers should be disconnected and inspected for damage.
- The bottom of the risers where the rings are attached , should be massaged with your hands to keep the webbing supple.
- The main load ring(where the risers attach) should be inspected for damage.
- The cutaway cable should be removed from the system and cleaned then inspected.
- The cutaway cable housings/clamps should be inspected.
- The riser system should be assembled and checked after maintenance.

Tom Parker
Chief Engineer
Sun Path Products Inc.