

MIRAGE SYSTEMS, INC.

AAD INSTALLATION IN MIRAGE CONTAINERS

Owners Manual Addendum December, 2004

The following Cypres installation instructions supersede all Mirage G3, G4, and RTS Owners Manual Instructions per product service bulletin 12-04.

1. For improved performance, the location of the AAD cutter has been moved from the #1 flap to #3 flap. A channel to route the cutter has been created in the midwall and #3 flap, beginning at a small slit in the midwall near the AAD pouch.
2. Install the AAD control unit in the pre-installed pocket as usual.
3. For ease of installation, a length of hand-tack cord has been factory-installed through the AAD cutter channel in the #3 flap. Use this cord to draw the AAD cutter through the channel during initial assembly, then discard it. If the initial assembly does not include an AAD, this cord MUST be removed from the channel and discarded prior to packing the reserve.
4. If the hand-tack thread cord is not in place, use a bodkin or similar tool to draw a pull-up cord through the cutter channel, then use this cord to draw the AAD cutter through the channel. See figure below.



5. Ensure that the hand-tack draw cord has been removed and discarded prior to closing the reserve. Stow all excess cable.

For additional questions, please contact our technical department at tech@miragesys.com or by phone at 386-740-9222.