

**Installation instructions:
Connecting a main canopy to PMI Main
Risers using Soft Links**





Locate the dive loop area
and the top riser loop of
the riser.

Group together as shown
below



Pinch both layers of Type 17 together about ½ way back from the top of the loop. (dots indicate pinch location)





Install the soft link the pinch location

CRITICAL NOTE: SOFT LINK WILL GO AROUND BOTH LAYERS OF TYPE 17, DIVE LOOP AND TOP RISER LOOP

Once the soft link is properly installed, pull the line group upwards, this will set the soft link and put it in the proper location at the top of the riser.

