



PARACHUTES AUSTRALIA

22 Bosci Road,
Ingleburn, N.S.W. AUSTRALIA 2565
Ph: 02 98295355 Fax: 02 98291300

INSTALLATION INSTRUCTION FOR "KILL-LINE" COLLAPSIBLE PILOTCHUTE SYSTEM PT:B047-TB

Step 1 (Refer to Figure 1.)

- Take note of how the Rapide Link is installed onto the bridle.
- Remove the Rapide link from both loops of the end of the bridle.
- Pass the assembly through the bag grommet until stopper 'B' is up against the grommet
- Place the link through both loops at the end of the bridle with the kill-line through the centre of the link
- Tighten the link
- Pass the loop at position 'G' through the attachment point to the canopy
- Starting with the pilotchute pass the whole kill-line system through loop 'G' to anchor.

Step 2

- Before placing the canopy into the deployment bag the pilotchute will have to be 'armed'
- This is best done by placing your foot on the deployment bag positioned close to the canopy attachment point. Hold the bridle with one hand at about mid point at 45 degrees away from your body and extend the top of the pilotchute with your other hand until nearly all of the kill-line has been extracted through the bridle into the pilotchute.
- You may check the arming position through the small window located approx. 40mm from the curved pin. (Refer Figure 2)
- Packing is now carried out normally with the excess webbing (Part G below) stowed freely inside the deployment bag free of twists.

Figure 1 References.

- | | |
|------------------------------------|-------------------------------|
| A) Bridle | E Spectra Kill-line |
| B) Deployment Bag Grommet Stopper | F Collapsible Setting |
| C) Deployment Bag Grommet Position | G Loop for Canopy Attachment. |
| D) Rapide Link | |

