



U-STOW MAIN DEPLOYMENT BAG PACKING METHOD

1.



Prepare the main bag by installing the main pilot chute bridle and opening the tuck flaps.

2.



Attach the bridle to the main canopy Pilot Chute Attachment (PCA).

3.



Insert the prepared canopy into the man deployment bag keeping the lines under tension.

4.



Rotate the deployment bag up upwards keeping the suspension lines in the center.

5.



Make your first locking stow.

6.



Make your second locking stow.

*Depending on the bag size 2,3 or 4 stows are needed.

7.



Route lines from the locking stows over the top of the bag to the bottom of the line stow pouch.

8.



Use your thumb to form the first figure 8

9.



Continue figure 8 line placement into pouch stacking each placement upon the previous.

10.



Ensure the line stows are as wide as the pouch.

11.



Continue to stow remainder of lines.

12.



The last line stow should finish in the center between the two tuck tabs.

13.



With the deployment bag upright, close both tuck tabs making sure not to pinch the lines into tab pocket.

14.



Close the second tuck tab.

15.



The U stow main bag is now closed.